





# Laboratoire DuboisTesting Watches and More Wearable 2016/EPFL

Yvan Terés Silvano Freti







#### Testing Watches and More

#### **OUTLINE**

- Introduction
- Traditional watch vs wrist wearable
- Usual tests for traditional watches
- Compliance issues
- Comparing some standards
- Conclusions





Testing Watches and More

#### **OUTLINE**

- Introduction
- Traditional watch vs wrist wearable
- Usual tests for traditional watches
- Compliance issues
- Comparing some standards
- Conclusions







Testing Watches and More

#### WHO ARE WE?

- A privately owned Swiss Laboratory
- Located in La Chaux-de-Fonds
- Created 40 years ago
- Serving the traditional watch industry since about 3 decades
- Specialised in watch reliability





#### Testing Watches and More

#### WHO ARE WE?

- Organised in 5 BU
  - Watches and micro- mechanisms
  - Material science
  - Flexible materials
  - Chemistry and chemical compliance
  - Monitoring regulations and standards
- Acting actively on watch industry standards
  - NIHS (Swiss Watch Industry Standards)
  - ISO TC 114
- With a broad range of accredited activities according to ISO 17025

For further info, see www.laboratoiredubois.ch





Testing Watches and More

#### **OUTLINE**

- Introduction
- Traditional watch vs wrist wearable
- Usual tests for traditional watches
- Compliance issues
- Comparing some standards
- Conclusions







Testing Watches and More

#### TRADITIONAL WATCH VS WRIST WEARABLE



- Both face the same environment!
  - Movements, accelerations and shocks
  - Sweat
  - Salty atmosphere
  - Water
  - Magnetic fields
  - Sun ray (UV exposure)
  - Abrasive surfaces
  - Heat
  - ...







Testing Watches and More

#### TRADITIONAL WATCH VS WRIST WEARABLE

- Should keep its functions during the entire lifetime
- Should keep a good aspect over ageing
- May show some kind of water resistance
- Should be safe and comply to legislations







Testing Watches and More

#### TRADITIONAL WATCH VS WRIST WEARABLE













Testing Watches and More

#### TRADITIONAL WATCH VS WRIST WEARABLE

And even worse...











Testing Watches and More

#### **OUTLINE**

- Introduction
- Traditional watch vs wrist wearable
- Usual tests for traditional watches
- Compliance issues
- Comparing some standards
- Conclusions







#### Testing Watches and More








- Movement/Watch head
- Watch case
- Bezel
- Wristlet (metal, leather, rubber...)
- Clasp
- Dial
- Hands













Testing Watches and More

#### NIHS AND ISO STANDARDS FOR WATCHES

#### Watch head

- Mechanical reliability tests (NIHS 91-30 and 93-20)
- Water resistance (ISO 22810 and 6425)
- Shock resistant wrist watches (ISO 1413)
- Magnetic resistant watches (ISO 764)
- Wrist-chronometers with spring-balance oscillator (ISO 3159)

#### Watch case and accessories

- Climatic requirements for watch surrounding (NIHS 96-50)
- Tests of the resistance to wear, scratching and impacts (ISO 23160)
- Mineral and sapphire watch-glasses (ISO 14368)









#### Testing Watches and More




- Shock-resistant wrist watches (ISO 1413)
  - Consist 2 set of impacts equivalent to a free fall of 1m on "hard wood"
    - First set of 3 impacts on the watch head only







Second set of 2 free fall of the entire watch





If the watch comply to the requirements a marking can be added as "shock-resistant"






Testing Watches and More

#### NIHS AND ISO STANDARDS FOR WATCHES

- Magnetic resistant watches (ISO 764)
  - Exposing the watch to a DC field of 4800 A/m



- Measuring the residual effect on the movement
- If the watch comply to the requirements a marking can be added as "magnetic-resistant"







#### Testing Watches and More



Synthetic sweat test under controlled temperature

#### NIHS AND ISO STANDARDS FOR WATCHES

Climatic requirements on watch surrounding (NIHS96-50)



Watch case after salt spray test



UV test on leather strap






Testing Watches and More

#### NIHS AND ISO STANDARDS FOR WATCHES

 Tests of the resistance to wear, scratching and impacts (ISO 23160)






Vibration wear with ceramic chips



Multidirectional mvt with fine silica powder



Free fall test in ceramic chips bed





### Testing Watches and More




Mineral and sapphire watch glasses (ISO14368)

Defect assessment

Hardness measurement HK

 Measuring the cracking energy by a free fall ball test

 The standard specify two grades of mineral glasses



© Laboratoire Dubois / Wearable 2016





Testing Watches and More

#### PROPRIETARY AND OTHERS TESTS

- Movement/Watch head
  - Chronofiable® reliability protocol
  - Multiple shocks protocol
  - Functions ageing
  - Mechanism ageing
- Wristlet and clasp
  - Random movements
  - Tensile torsion
  - Alternate movements
  - Clasp ageing




Testing Watches and More

S SCHWEIZERISCHER PRÜFSTELLENDIENST SERVICE SUISSE D'ESSAI SERVIZIO DI PROVA IN SVIZZERA


#### **PROPRIETARY TESTS**

Chronofiable® reliability protocol, includes heat and moisture cycles
Simulation of 6 months wearing

effects in 21 days







25 and 100 G






#### Testing Watches and More

#### **PROPRIETARY TESTS**

- Multiple shock customized protocols
  - Accredited STS from 10 to 1000G
  - Tests on watch heads, smart watches, movements in containers, micro mechanisms, sensors, MEMS...












Testing Watches and More

#### **PROPRIETARY TESTS**

Functions ageing



Applying cycles on rotating bezel





Ageing setting stem (winding, pull-push, date, hand-setting)

© Laboratoire Dubois / Wearable 2016






Testing Watches and More

#### **PROPRIETARY TESTS**

Functions ageing





Chronograph push-piece: recording push force as function of position








#### Testing Watches and More



#### **OTHERS TESTS**

- Wristlet and clasp
  - Random movements
  - Pull-Twist test
  - Alternate movements













Testing Watches and More

#### **OTHERS TESTS**

- Wristlet and clasp
  - Clasp ageing













Testing Watches and More

#### **OTHER TESTS**

- Wristlet and clasp
  - Wear
  - Mechanical strength
  - Resistance to ozone cracking (ISO1431-1)











Testing Watches and More

#### **OUTLINE**

- Introduction
- Traditional watch vs wrist wearable
- Usual tests for traditional watches
- Compliance issues
- Comparing some standards
- Conclusions







Testing Watches and More

#### **COMPLIANCE ISSUES**

- Mechanical vs quartz watches
  - Pure mechanical watches shall comply in Europe with REACH regulation
  - Quartz watches shall comply with RoHS and REACH
- Wearables shall comply to both
- REACH restrictions are quite simples for metallic items
  - Lead and Cadmium content are limited
  - Limitation of nickel release for items in direct and permanent contact with the skin EN 1811







#### Testing Watches and More



#### **COMPLIANCE ISSUES**

- REACH restrictions are much more complex for leather, textile and rubber materials in contact with skin, for example
  - Chromium VI in leathers (ISO 17075)
  - Azo dyes in leather and textiles
  - PAHs (polycyclic aromatic hydrocarbons) in rubber and plastics
- Products for children face higher requirements
- WEEE directive for electrical & electronic equipment apply for wearables and quartz watches





Testing Watches and More

#### **OUTLINE**


- Introduction
- Traditional watch vs wrist wearable
- Usual tests for traditional watches
- Compliance issues
- Comparing some standards
- Conclusions








#### Testing Watches and More



Mechanical Shocks NIHS 91-30 vs IEC 60068-2-27

#### **COMPARING STANDARDS**



Désignation du choc	Accélération (Valeur crête) A (g)	Durée τ (ms)	Variation de vitesse ∆ ∨ (m/s)	
(25/5)	25	5	0,8	
(100/2)	100	2	1,3	
(500/0,7)	500	0,7	2,2	

Peak acceleration (A)		Corresponding duration of the nominal pulse (D)	Half-sine $\Delta V = 2/\Pi \text{ AD} \times 10^{-3}$	
m/s <sup>2</sup>	g <sub>n</sub>	ms	m/s	
250	25	6	1	
1 000	100	2	1,3	
5 000	500	1	3,2	

© Laboratoire Dubois / Wearable 2016






Testing Watches and More

Water resistance ISO 22810 vs IEC 60529

#### **COMPARING STANDARDS**

- The watch ISO 22810 comprises the following set of tests:
  - Water overpressure, min 2, typ. 3 bar/10 min
  - Low depth immersion 10cm/1h min
  - Low depth immersion 10cm/5min while applying an orthogonal load





- Low depth immersion 10cm/5 min at different temperatures sequentially 40-20-40 °C
- If the watch comply to the requirements, it can be marked "water resistant"





Testing Watches and More

#### **COMPARING STANDARDS**

■ The IEC 60529 (IP code) proposes 8 requirement levels for water resistance

Water resistance ISO 22810 vs IEC 60529

Second charac- teristic numeral	Test means	Water flow rate	Duration of test	Test conditions, see
7	Immersion tank Water-level on enclosure: 0,15 m above top 1 m above bottom	-	30 min	14.2.7
8	Immersion tank Water-level: by agreement	-	by agreement	14.2.8

 Only 8+ level would offer similar severity as the watch standard





Testing Watches and More

#### **OUTLINE**

- Introduction
- Traditional watch vs wrist wearable
- Usual tests for traditional watches
- Compliance issues
- Comparing some standards
- Conclusions





Testing Watches and More

#### **CONCLUSIONS**

- Non expressed customer expectations beside functions are almost similar for traditional watches and wristlet wearables
- Legislation requirements although poorly communicated to the customers are highly overlapping





Testing Watches and More

#### **CONCLUSIONS**

- A common set of requirements lead to an non common set of standards through differences in technologies and professional sectors
- The Wearable community may take advantages being aware of existing standards in traditional watch industry.





Testing Watches and More







## Many thanks for your attention

www.laboratoiredubois.ch